


Hook-A

Self-releasing towing hook
for **EffiBOT**





Hook-A

Hook-A is a trailer hook for **EffiBOT**. With its **automatic release function**, it allows the **EffiBOT** to transfer trailers to different destinations in the factory or warehouse.

Hook-A is compatible with our range of **Shaped Trailers**, but can also be used with your own trailers.


This accessory uses **safety electronics (PL-d level)** that continuously control and monitor the trailer hook-up.

Benefit from the **Follow-me 360°** collaborative technology, the **EffiBOT**, attached to a trailer, assists your operators in moving heavy loads.






Use cases



<https://youtu.be/9LS5vTRzsRE>





<https://youtu.be/mNk3zUDSpOY>





The Hook-A accessory


- **Hook-A** is an accessory that is installed on the end of the **EffiBOT**. The robot must have the hitch option (*black docking base*).
- Insert the **Hook-A** chain into the **EffiBOT** docking base and lock the assembly with 2 vertical pins.
- Connect the power cable and data cable to the **EffiBOT**'s side sockets.





The Hook-A accessory



- The drawbar of the trailer must have a vertical axis and be manually inserted into the **Hook-A** hook.
- **EffiBOT** is ready to move, either **autonomously** or in **Follow-Me**, followed by its trailer.
- The trailer can be uncoupled automatically by the **EffiBOT** either from predefined positions in the mapping software or from an order received by the fleet server.
- The trailer can also be uncoupled **manually** by operating a lever.





Illustrated functioning



- Manually place your trailer tongue pin into the **towing bracket**.
- The **Hook-A automatic striker** hooks and locks your trailer tongue pin.
- Once **EffiBOT** has reached its release zone, it will unlock to release the trailer pin.
- A **manual release** is available by activating the lever. This lever, when closed, blocks the striker to **lock it**. When open, it releases the striker to **unlock it**.





Cinematics, size and obstacles

- The trailer towed by **EffiBOT** is not equipped with an obstacle sensor. It is therefore up to the **EffiBOT** robot to ensure that there are no obstacles around it that could be hit by the trailer it is towing.
- Also, when a **trailer is attached**, the width of the **EffiBOT** is **virtually increased** on the left and right by a safety margin.





Safety first architecture

- The **Hook-A** electronic system has been designed according to **ISO 13849**: "Safety-related parts of control systems". It is a Category 2 safety architecture with a **SIL2 / PLd performance level**.
- This electronic system prevents the **EffiBOT** from moving until the lock is fully locked or unlocked. When the **EffiBOT** is moved, it ensures that the strike plate remains stationary.
- When a trailer is attached, the dimensions of one and only one previously stored trailer are transmitted to the **EffiBOT** for obstacle management.
 - ✓ Redundant microcontrollers (main channel and test channel)
 - ✓ Redundant inverted logic sensors for opening hook pairs
 - ✓ Redundant inverted logic sensors for closing the hook pairs
 - ✓ Redundant inverted logic emergency stop outputs connected to the motors' STO (Safe Torque Off) input





Hook-A & EffiBOT, configuration

- Our **Hook-A** system is compatible with our **Shaped Trailers** range of trailers. It can also be on yours, depending on its characteristics!



FlatShape



C-Shape








Effidence
Intelligence for mobile robotics

www.effidence.com

23 Rue de la Roseraie, 63540
Romagnat

+33 (0)4 73 25 15 26

sales@effidence.com



Hook-A

